
## CHO1024 Single IR Emitter CHO1025 Dual IR Emitter Information and Installation Guide

# C. Installation

#### Standard installation






1. IR emitter (flat side) attached

directly to IR sensor window


#### A. Description

- 1. Round, compact size with built-in Infrared transmitter
- 2. 10 feet cable length with 3.5mm mono standard plug
- 3. Self-adhesive tape for quick and easy fixing on any hard, clean & dry surface.

#### B. Diagram




#### Attach IR emitter to the inside of shelf



1. Attach IR emitter on, above, or below of the IR window

### Cabinet With door Installation



 IR emitter is attached to rack door, round shape side facing the IR window

#### Choice Select Dual IR Emitter with 10 ft. Cable and 1/8 in. Male Part No. 47-600-004

#### D. Note:

- 1. (NOTE: make sure mounting surface is clean and dry before affixing the IR emitter)
- 2. Do not connect IR emitter directly to power supply or battery